

VDCP

Requirements

- Video Server Control software option
- If you are using multiple video channels on the VDCP video server, each channel should be assigned to a separate **Remote Port**, or a **Port Expander** should be used.
- Serial Interface Cable (DB9 to DB9)
- Control DeviceMaster or Sealevel SeaLINK
- Ethernet Cable

Port Connections

Serial Communication		
Video Server RS-422	>	DeviceMaster or SeaLINK RS-422
DeviceMaster or SeaLINK Ethernet	>	Local Area Network Ethernet

Ethernet Communication		
Video Server Ethernet	>	Local Area Network Ethernet

Video		
Switcher Input BNC	>	Video Server Video Out BNC

For More Information on...

- configuring switcher inputs, refer to the *Caprica User Guide*.

Network Connections


Serial

VDCP video servers that use a serial connection to communicate require an Ethernet to serial server to connect to the Caprica Server. When configuring a serial connected VDCP video server, start with section “**Serial Interface Cable Pinouts**” on page 4–1.

Ethernet

VDCP Video servers that use an Ethernet connection can directly connect to the Caprica Server. When configuring an Ethernet connected video server, start with section “**Remote Device Port Configuration Settings**” on page 4–3.

Serial Interface Cable Pinouts



DeviceMaster

DeviceMaster	
Pin	Signal
2	RxA (Rx-)
7	TxB (Tx+)
8	RxB (Rx+)
3	TxA (Tx-)

SeaLINK

SeaLINK	
Pin	Signal
2	RxA (Rx-)
4	TxB (Tx+)
1	RxB (Rx+)
3	TxA (Tx-)

- ★ When using a SeaLINK Ethernet to serial server in your OverDrive system, terminate any control signals that are not going to be used. The most common way to do this is connect RTS to CTS, connect positive to positive and negative to negative.

Configuring the Ethernet to Serial Server

The Ethernet to serial server in an OverDrive system handles the communication between your VDCP video server and Caprica Server. OverDrive systems can contain a DeviceMaster or SeaLINK Ethernet to serial server. Use one of the following sections to configure the Ethernet to serial server in your OverDrive System:

- “**DeviceMaster**” on page 4–2
- “**SeaLINK**” on page 4–2

DeviceMaster

The VDCP video server connects to a serial port on the DeviceMaster. Use the following procedure to configure the DeviceMaster for your VDCP video server:

1. Use a web browser to open the **Server Status** web page for your DeviceMaster. The default IP address for a DeviceMaster is 192.168.250.250.
The **Server Status** web page opens in the web browser.
2. Click **Port #** link, where # is the port number on the DeviceMaster to which you connect your VDCP.
The **Edit Port # Configuration** web page opens for the selected port.
3. In the **Port Name** box, enter *Abekas Mira*.
4. In the **Serial Configuration** section, use the **Mode** list to select **RS-422**.
5. Use the **Baud** list to select **38400**.
6. Use the **Parity** list to select **odd**.
7. Use the **Data Bits** list to select **8**.
8. Use the **Stop Bits** list to select **1**.
9. Use the **DTR** list to select **off**.
10. Use the **EOL** list to select **disabled**.
11. In the **TCP Connection Configuration** section, select the **Enable** check box.
12. Select the **Listen** check box.
13. In the **Port** box, enter the port number that the DeviceMaster uses to listen for communication from the VDCP.
14. Click **Save**.
The **Port Configuration Updated** web page opens.
15. Click **OK**.
The **Server Status** web page opens.
16. Click **Reboot**.
The DeviceMaster reboots with the new configuration.


SeaLINK

The VDCP video server connects to a serial port on the SeaLINK. You must configure the connected SeaLINK serial port to communicate with the VDCP video server.

Hardware Configuration

The SeaLINK Ethernet to serial server is primarily configured using the web interface. Before using the web interface, the SeaLINK DB9 port that connects the VDCP video server to your OverDrive system requires DIP Switch configuration.

Inside the SeaLINK each DB9 serial port has a set of eight DIP Switches. To communicate with the VDCP video server the RS Mode of the DB 9 serial port that connects the VDCP video server must be set to RS-422. Set the DIP Switches associated with the connected port as follows:



DB9 DIP Switch Settings for RS-422

For More Information on...

- configuring the DIP Switches for SeaLINK DB9 ports, refer to the **Hardware Configuration** section in the *SeaLINK User Manual | Ethernet Serial Server Family*.

Web Interface Configuration

After setting the DIP Switches associated with the DB9 port on the SeaLINK used to connect the VDCP video server, you can use the SeaLINK web interface to complete the SeaLINK configuration.

Use the following procedure to configure the SeaLINK for your VDCP video server:

1. Use a web browser to open the **Summary** web page for your SeaLINK. The URL of the Summary web page is the IP address of the SeaLINK.
The **Summary** web page opens in the web browser.
2. Click the **Port Settings** tab.
The **Port Settings** web page opens.
3. In the **Port # Defaults Section** section, where # is the port number on the SeaLINK to which you connect your VDCP video server, enter 38400 in the **Baud Rate** box.
4. Use the **Data Bits** list to select **8**.
5. Use the **Stop Bits** list to select **1**.
6. Use the **Parity** list to select **None**.

7. Use the **Flow Control** list to select **None**.
8. Use the **RS Mode** list to select **RS 422/488**.
9. Use the **Protocol** list to select **Ignored**.
10. Click **Submit**.
11. Click the **Administration** tab.
The **Administration** web page opens.
- ★ Values set for settings on the **Administration** web page are set for all SeaLINK serial ports.
12. In the **General Settings** section, enter a name to identify the SeaLINK in the **Name** box.
13. Use the **Connection Protocol** list to select **Raw Data**.
14. At the bottom of the **Administration** web page, select the **Reboot** check box.
15. Click **Submit**.
The SeaLINK reboots with the new configuration.

Remote Device Port Configuration Settings

Use the following procedure to configure a remote device for your VDCP on the Caprica Server:

1. Use the current version of **DashBoard** software to connect to your **Caprica Server**.
2. In the **DashBoard Tree View**, double-click the **Port Configuration** node of your Caprica Server.
3. In the **Port Configuration Summary** table, double-click a **REMOTE#** port in the **Port** column.
4. In the **Configure REMOTE#** panel, click **Server/VTR**.
5. Click **VDCP**.
6. Click **Network Settings**.
7. Use the following settings to configure the network settings for your VDCP video server:
 - **Ethernet Role** — Client
 - **Remote IP Address** — IP address of the Ethernet to serial server in your OverDrive system
 - **Remote Port** — Port number on the Ethernet to serial server to which you connect your VDCP video server.
When using a SeaLINK Ethernet to serial server in your OverDrive system the Remote Port number is associated with the SeaLINK serial port number to which you connected your VDCP video server. The

SeaLINK serial port to Remote Port associations are as follows:

SeaLINK Serial Port	Remote Port
1	4680
2	4681
3	4682
4	4683

- **Local IP Address** — 0.0.0.0
 - **Local Port** — 0
 - **Protocol** — TCP
8. Click **Apply Changes** to save the network settings.

Device Settings

Use the following procedure to configure the device settings for your VDCP video server on the Caprica Server:

1. Click **Device Settings**.
2. Use the following settings to configure the device settings for your VDCP video server:
 - **TargetMachine** — click to select the model of video server to configure.
 - **Timeout** — enter or select the time, in fields, that the Caprica will wait for a reply from the video server before trying to resend a command, **5** to **60** fields.
 - **Cmd Queuing** — click the option to set whether Caprica requires a replies for each command sent to the video server. The available options are as follows:
 - › **Strict** — resend a command, as defined by the Send Tries setting, until Caprica receives a confirmation message from the video server.
 - › **Relaxed** — do not require a confirmation message from the video server for each command that Caprica sends to the video server.
 - **Playback Mode** — click the playback mode that the video server uses. The available options are as follows:
 - › **PB** — video servers that do not go to EE (Electronic-to-Electronic) mode.
 - › **PB/EE** — video servers that do go to EE mode. When the video server receives a Pause command it stays in PB (Playback) mode. When the video server receives a Stop command it goes to EE mode.

- **ExtendedChar** — click the option to set whether Caprica uses the extended character set for ClipIDs. The available options are as follows:
 - › **No** — replace non-printing characters in ClipIDs with spaces.
 - › **Yes** — use the extended character set for ClipIDs instead of replacing non-printing characters with spaces.
- **Clip List** — click the clip list with which to associate the video server. The available options are:
 - › **Clip List A** — cached clip list for fast access.
 - › **Clip List B** — cached clip list for fast access.
 - › **Floating list**

Each clip list can only be associated with one physical video server.
- **Play w/Alpha** — click the option to set whether Caprica plays the alpha channel with the video channel. The available options are as follows:
 - › **No** — only play the video channel from the video server.
 - › **Yes** — play both the video and alpha channels from the video server. With this option, the switcher does not check the status of the video server channels before sending the play command.

Both the video and alpha input BNCs must have the video server assigned to them, and must be set up as an auto key to associate the video with the alpha.
- **Eject Clip** — click the option to set whether Caprica instructs the video server to eject the current clip before cueing the next clip. The available options are as follows:
 - › **No** — do not eject the current clip before cueing the next clip.
 - › **Yes** — eject the current clip before cueing the next clip.
- **Status Tries** — enter or select the number of times that Caprica will send a status check request to the video server without receiving a ready response, **5 to 60**.
- **Panel** — in a MultiPanel system, click to setting to select the control panel to which the video server is connected.
- **MediaIDLength** — click the maximum character length of the Clip IDs displayed by Caprica. The available options are as follows:
 - › **Short IDs** — devices that use ID lengths of up to 8 characters.
 - › **Long IDs** — devices that use ID lengths of up to 32 characters.
- **Send Tries** — enter or select the number of times that Caprica will try to send the same command to the

video server if it does not receive a confirmation response, **1 to 15**.

- **Record Time** — enter or select the maximum time that a video server records when it receives a Record transport command from a custom control, **1 to 720** minutes.
 - **Port Cmds** — click the option to set whether the video server supports the Open Port, Select Port, and Close Port commands. The available options are as follows:
 - › **No** — video servers that do not support the Open Port, Select Port, and Close Port commands.
 - › **Yes** — use the Open Port, Select Port, and Close Port commands when entering or exiting VDCP menus.
 - **LoopRecueTime** — enter or select the amount of time before the end of the clip that Caprica sends a loop command to the video server, **1 to 20** frames.
 - **LoopMinLength** — enter or select the minimum length of a clip that can be looped, **3 to 30** seconds.
 - **Cue & Pause** — click the option to set whether Caprica sends a Pause command to the video server immediately after a Cue command. The available options are as follows:
 - › **No** — do not send a Pause command to the video server immediately after a Cue command.
 - › **Yes** — send a Pause command to the video server immediately after a Cue command. This option enables the video server cue a clip and advance it so that you can preview the first frame of the clip.
 - **StatusInterval** — enter or select the amount of time that Caprica waits between status check requests of the video server, **2 to 30**.
 - **Preroll** — enter or select the amount of time to delay before transitioning to the video server, **0 to 150** frames.
 - **Play Skip Q** — click the option to set whether Caprica allows the Play command to skip the commands queued for a channel on the video server. The available options are as follows:
 - › **No** — add the Play command to the end of the command queue for the channel to play, then execute commands from the queue in order.
 - › **Yes** — execute the Play command as soon as possible, skipping the commands in the command queue for the channel to play.
3. Click **Apply Changes** to save the device settings.
 4. Click **Done** to close the Configure REMOTE# panel.

For More Information on...

- configuring remote devices for OverDrive systems that contain a Caprica Server, refer to the *Caprica User Guide*.

Device Setup

If the device is communicating properly, but you cannot gain control from the switcher, try cycling through different values for the SubAddress, and then the Channel. The most common settings are as follows:

- Channel set to the video channel number and SubAddress set to 0.
- Channel set to the video channel number and SubAddress set to the serial communications port on the video server.

Compatibility

Video Server	Version
VDCP	-

Automation	Version
OverDrive	17.1 or higher
Caprica Server	4.1a or higher

Port Expanders	Support
Control DeviceMaster	Yes
Sealevel SeaLINK	Yes

Contacting Technical Support

Technical Support is staffed by a team of experienced specialists ready to assist you with any question or technical issue.

Ross Video has technical support specialists strategically located around the globe to ensure a prompt response to technical inquiries. Our primary technical support center is located in Ottawa, Ontario, Canada. In addition, we have offices in The United Kingdom (London), Australia (Sydney), and Singapore with satellite locations in New York City, The Netherlands, and China. As we expand our presence globally, we are constantly evaluating other key locations to have a local technical support specialist in order to better service our customers.

North America

Our North America center located in Ottawa, Ontario, Canada and is open Monday to Friday 8:30 a.m. to 6:00 p.m. EST, with 24/7/365 on-call service after hours.

Our telephone number is: +1-613-686-1557

Toll free within North America: +1 833-859-0499

EMEA

Our EMEA center is open Monday to Friday 8:30 a.m. to 5:00 p.m. GMT. After hours support is provided by our North America location.

Our telephone number is: +44 (0)1189502446

International toll free: +800 3540 3545

If the local support specialist is not available, your call will be transferred automatically to our North America center.

Australia

Our Sydney, Australia office is located in Alexandria, NSW.

Our local support telephone number is: 1300 007 677

If the local support specialist is not available, your call will be transferred automatically to our North America center.

Online

E-mail: techsupport@rossvideo.com

Website: open a support request using the link <https://support.rossvideo.com/> to open a support request.

Copyright

© 2014 - 2024 Ross Video Limited. Ross®, MLE®, OverDrive®, GlobalView®, RundownControl™, DirectControl™, DirectAudio™, DirectAUXaudio™, DirectCamera™, DirectServer™, QuickTurn™, RapidRestore™, SideShot™, SideSlide™, SideStick™, OverDrive Gateway™, LiveLink™, and any related marks are trademarks or registered trademarks of Ross Video Limited. All other trademarks are the property of their respective companies. PATENTS ISSUED and PENDING. All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, mechanical, photocopying, recording or otherwise, without the prior written permission of Ross Video. While every precaution has been taken in the preparation of this document, Ross Video assumes no responsibility for errors or omissions. Neither is any liability assumed for damages resulting from the use of the information contained herein.