

RossAutomation

Supported Editors

These setup instructions apply to any editors using the Ross Automation editor protocol.

Requirements

- Editor Interface Software Option
- Ethernet Cable

Port Connections

	Switcher		Editor
Communications	PERIPH Port (female)	⇒	Network TCP Port

Switchers	
Synergy 1 SD	--
Synergy Series SD	--
Synergy MD/X	--
Vision MD/X	--
Vision QMD/X	16.0a
Vision MultiPanel Support	--
Port Expanders	
BSS4	✘
Control DeviceMaster	✘

Switcher Setup

1. Press **HOME** ⇒ **Setup** ⇒ **Installation** ⇒ **Com Setup** ⇒ **Type**.
 - Use the **Com Port** knob to select the **PERIPH X** port that you connected the Ross Automation editor to.
 - Use the **Device** knob to select **Editor**.
2. Press **Editor Protocol**.
 - Use the **Device** knob to select **RossAuto**.
3. Press **Com Type**.
 - Use the **Type** knob to select **Network TCP**.
4. Press **Com Setting**.
5. Use the **Client/Server** knob to select **Server**.
 - In the **Local IP Address** field, enter **0.0.0.0**.
 - Leave the **Local IP Port** field as is
6. Press **HOME** ⇒ **Confirm**.

Note: The **Editor** remote enable, or button, must be turned on for the editor to control the switcher (**Home** ⇒ **More** ⇒ **Remote Enables**).

Device Setup

Ensure the port on the Ross Automation editor that is connected to the switcher is configured for Network TCP.

Compatibility

Editor	Version
RossAutomation	--





Video Production Technology