




IGGY-ANA8.8 Installation



Before you set up and operate your IGGY-ANA8.8 see the "Important Regulatory and Safety Notices" that shipped with your unit. It is also recommended to refer to the *IGGY-ANA8.8 User Guide*. The *IGGY-ANA8.8 User Guide* is available for download from our website.

Mounting via Tie-wraps

Refer to the guide that shipped with your install kit for additional details.



Reference Cabling (Optional)



Network Cabling

To Network 1 To Network 2 To Facility Network




The IGGY-ANA8.8 can be powered from a PoE+ (802.3at Type 2) power source (PSE) connected to the NET1 port.

ANALOG Cabling



ANALOG IN 1-8




ANALOG IN 1-8 Port on the IGGY-ANA8.8 — Pinouts

ANALOG	PINs			
	H	C	G	
IN 1	24	12	25	
IN 2	10	23	11	
IN 3	21	9	22	
IN 4	7	20	8	
IN 5	18	6	19	
IN 6	4	17	5	
IN 7	15	3	16	
IN 8	1	14	2	

H = Hot (+)
C = Cold (-)
G = Ground

ANALOG OUT 1-8



ANALOG OUT 1-8 Port on the IGGY-ANA8.8 — Pinouts

ANALOG	PINs			
	H	C	G	
OUT 1	24	12	25	
OUT 2	10	23	11	
OUT 3	21	9	22	
OUT 4	7	20	8	
OUT 5	18	6	19	
OUT 6	4	17	5	
OUT 7	15	3	16	
OUT 8	1	14	2	

H = Hot (+)
C = Cold (-)
G = Ground


DC Power Connection



The power supply connector of the IGGY-ANA8.8 power supply module must be fully inserted into the IGGY-ANA8.8 PWR port and the locking collar fully secured before use. Failure to do so may damage the PWR port on the IGGY-ANA8.8 chassis.



Ensure to connect the DC Power cord of the power supply to the PWR port on the IGGY-ANA8.8 chassis before connecting the power supply to the power source.



Assigning the IP Address

To assign the IP Address to the IGGY-ANA8.8

1. Verify that the **NET 1** port of your IGGY-ANA8.8 is connected to the same local network that your PC is connected to (i.e., so they are plugged into the same ethernet switch).
2. Verify that the IGGY-ANA8.8 is powered on.
3. Locate the serial number label on the side of your IGGY-ANA8.8.
4. Perform one of the following:
 - Scan the QR code on the serial number label, or
 - Use a browser to go to: www.rossvideo.com/device and enter the serial number.
5. Review the information reported about your IGGY-ANA8.8.
6. Select Local Link to launch the IGGY-ANA8.8 web UI and open the Welcome page.
7. Select the Initial Setup tab at the top.
8. Follow the on-screen instructions to quickly set up the IP Address and user settings.



Refer to the *IGGY-ANA8.8 User Guide* for setup via DashBoard.

Note: To reset the IGGY-ANA8.8, including the IP Address, to the default settings press the Reset button (located beside the POWER LED).



Have a question? Call our free, 24-hour technical support hotline to speak with a live product specialist located right here in our facility.

Tel: (+1) 613 • 652 • 4886

Email: techsupport@rossvideo.com

