



Ultracore-Tally Device Setup Guide

Thank You for Choosing Ross

You've made a great choice. We expect you will be very happy with your purchase of Ross Technology.

Our mission is to:

1. Provide a Superior Customer Experience
 - offer the best product quality and support
2. Make Cool Practical Technology
 - develop great products that customers love

Ross has become well known for the Ross Video Code of Ethics. It guides our interactions and empowers our employees. I hope you enjoy reading it below.

If anything at all with your Ross experience does not live up to your expectations be sure to reach out to us at solutions@rossvideo.com.



David Ross
CEO, Ross Video
dross@rossvideo.com

Ross Video Code of Ethics

Any company is the sum total of the people that make things happen. At Ross, our employees are a special group. Our employees truly care about doing a great job and delivering a high quality customer experience every day. This code of ethics hangs on the wall of all Ross Video locations to guide our behavior:

1. We will always act in our customers' best interest.
2. We will do our best to understand our customers' requirements.
3. We will not ship crap.
4. We will be great to work with.
5. We will do something extra for our customers, as an apology, when something big goes wrong and it's our fault.
6. We will keep our promises.
7. We will treat the competition with respect.
8. We will cooperate with and help other friendly companies.
9. We will go above and beyond in times of crisis. *If there's no one to authorize the required action in times of company or customer crisis - do what you know in your heart is right. (You may rent helicopters if necessary.)*

Ultracore-Tally · Device Setup Guide

- Ross Part Number: **2201DR-015-01**
- Revision: 1
- Release Date: January 23, 2025.
- Software Issue: **6.3**

The information contained in this manual is subject to change without notice or obligation.

Copyright

©2025 Ross Video Limited, Ross®, and any related marks are trademarks or registered trademarks of Ross Video Limited. All other trademarks are the property of their respective companies. PATENTS ISSUED and PENDING. All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, mechanical, photocopying, recording or otherwise, without the prior written permission of Ross Video. While every precaution has been taken in the preparation of this document, Ross Video assumes no responsibility for errors or omissions. Neither is any liability assumed for damages resulting from the use of the information contained herein.

Patents

Patent numbers US 7,034,886; US 7,508,455; US 7,602,446; US 7,802,802 B2; US 7,834,886; US 7,914,332; US 8,307,284; US 8,407,374 B2; US 8,499,019 B2; US 8,519,949 B2; US 8,743,292 B2; GB 2,419,119 B; GB 2,447,380 B; and other patents pending.

Notice

The material in this manual is furnished for informational use only. It is subject to change without notice and should not be construed as commitment by Ross Video Limited. Ross Video Limited assumes no responsibility or liability for errors or inaccuracies that may appear in this manual.

Maintenance/User Serviceable Parts

This product contains no user serviceable parts. If the unit does not appear to be working properly, please contact Technical Support using the numbers listed under the **“Contact Us”** section of this manual. This product is covered by a generous 1-year warranty and will be repaired without charge for materials or labor within this period. See the **“Warranty and Repair Policy”** section in this manual for details.

Environmental Information

The equipment may contain hazardous substances that could impact health and the environment.

To avoid the potential release of those substances into the environment and to diminish the need for the extraction of natural resources, Ross Video encourages you to use the appropriate take-back systems. These systems will reuse or recycle most of the materials from your end-of-life equipment in an environmentally friendly and health conscious manner.

The crossed-out wheeled bin symbol invites you to use these systems.



If you need more information on the collection, reuse, and recycling systems, please contact your local or regional waste administration. You can also contact Ross Video for more information on the environmental performances of our products.

Security and Privacy

If you would like more information on how Ross Video security and privacy practices have been applied to the Ultracore-Tally, what you should know about maintaining security of this product, and how we can partner with you to ensure security throughout this product's life-cycle, contact techsupport@rossvideo.com.

Ross Video has implemented reasonable administrative, technical, and physical safeguards to help protect against security incidents and privacy breaches involving a Ross Video product provided those products are used in accordance with Ross Video instructions for use. However, as systems and threats evolve, no system can be protected against all vulnerabilities and we consider our customers the most important partner in maintaining security and privacy safeguards. If you have any concerns, we ask that you bring them to our attention, and we will investigate. Where appropriate, we will address the issue with product changes, technical bulletins and/or responsible disclosures to customers and regulators. Ross Video continuously strives to improve security and privacy throughout the product life-cycle using practices such as:

- Privacy and Security by Design
- Product and Supplier Risk Assessment
- Vulnerability and Patch Management
- Secure Coding Practices and Analysis
- Vulnerability Scanning
- Access Controls appropriate to Customer Data
- Incident Response
- Clear paths for two-way communication between customers and Ross Video

If you would like to report a potential product related privacy or security issue (incident, breach, or vulnerability), contact techsupport@rossvideo.com.

Company Address



Ross Video Limited

8 John Street
Iroquois, Ontario, K0E 1K0
Canada

Ross Video Incorporated

P.O. Box 880
Ogdensburg, New York
USA 13669-0880

General Business Office: (+1) 613 • 652 • 4886

Fax: (+1) 613 • 652 • 4425

Technical Support: (+1) 613 • 652 • 4886

After Hours Emergency: (+1) 613 • 349 • 0006

E-mail (Technical Support): techsupport@rossvideo.com

E-mail (General Information): solutions@rossvideo.com

Website: <http://www.rossvideo.com>

Contents

Introduction	9
Documentation Conventions	9
Interface Elements	9
User Entered Text	9
Referenced Guides	9
Menu Sequences	9
Important Instructions	10
Contacting Technical Support	10
Before You Begin	11
Overview	11
System Requirements	12
Install the Tally System Console	12
Tally System Console and Ultricore BCS	13
Add the Ultricore BCS to the Tally System Console	13
Set up the Ultricore-Tally	13
Ross Production Switchers	15
Overview	15
Add the Ross Production Switcher to the Tally System Console	15
Settings for Ross Production Switchers	15
Apply the Updated Tally System Configuration	16
Specify a TCP Connection for Acuity	16
Import the Acuity Bus Maps to the Tally System Console	17
Bus Maps Interface	17
Ultrix Routers	19
Overview	19
Add Ultrix to the Tally System Console	19
Ultriscape Multiviewer	21
Overview	21
Add an Ultriscape Multiviewer to the Tally System Console	21
Configure the PiPs in the Tally System Console	21
Assign PiPs to Destinations	22
Apply the Updated Tally System Configuration	22
Third-Party Switchers	23
Add the Switcher to the Tally System Console	23
Settings for Third-Party Switchers	23
Apply the Updated Tally System Configuration	23
Third-Party Routers	25
Add the Router to the Tally System Console	25
Settings for Third-Party Routers	25
Apply the Updated Tally System Configuration	25

Third-Party Multiviewers	27
Add the Third-Party Multiviewer to the Tally System Console	27
Settings for Third-Party Multiviewers	27
Configure the PiPs in the Tally System Console	27
Assign PiPs to Destinations	28
Apply the Updated Tally System Configuration	28

Introduction

This guide covers the configuration of third-party devices to work within your Ross Ultracore-Tally. The following chapters are included:

- **“Introduction”** summarizes the guide and provides important terms, and conventions.
- **“Before You Begin”** provides information about the Tally System Console and how to install and configure it.
- **“Tally System Console and Ultracore BCS”** outlines how to add an Ultracore BCS to the Tally System Console.
- **“Ross Production Switchers”** summarizes the required steps for configuring the Tally System Console and Ultracore-Tally to interface with the Ross Production Switchers.
- **“Ultrix Routers”** summarizes the required steps for configuring the Tally System Console and Ultracore-Tally to interface with the Ross Ultrix routers.
- **“Ultriscape Multiviewer”** provides a general overview of the required steps for configuring the Tally System Console to interface with the Ultriscape Multiviewer on an Ultrix router.
- **“Third-Party Switchers”** provides a general overview of the required steps for configuring the Tally System Console to interface with third-party switchers.
- **“Third-Party Routers”** provides a general overview of the required steps for configuring the Tally System Console to interface with third-party routers.
- **“Third-Party Multiviewers”** provides a general overview of the required steps for configuring the Tally System Console to interface with third-party multiviewers.

Related Publications

It is recommended to consult the following Ross documentation before installing and configuring your devices:

- ***Tally System Console User Guide***, Ross Part Number: 2201DR-016
- ***Ultracore BCS User Guide***, Ross Part Number: 2201DR-106

Documentation Conventions

Special text formats are used in this guide to identify parts of the user interface, text that a user must enter, or a sequence of menus and sub-menus that must be followed to reach a particular command.

Interface Elements

Bold text is used to identify a user interface element such as a dialog box, menu item, or button. For example:

In the **Network** tab, click **Apply**.

User Entered Text

Courier text is used to identify text that a user must enter. For example:

In the **Language** box, enter `English`.

Referenced Guides

Text set in bold and italic represent the titles of referenced guides, manuals, or documents. For example:

For more information, refer to the ***TSI-4000 User Guide***.

Menu Sequences

Menu arrows are used in procedures to identify a sequence of menu items that you must follow. For example, if a step reads "**File** > **Save As**," you would click the **File** menu and then click **Save As**.

Important Instructions

Star icons are used to identify important instructions or features. For example:

- ★ Contact your IT department before connecting to your facility network to ensure that there are no conflicts. They will provide you with an appropriate value for the IP Address, Subnet Mask, and Gateway for your device.

Contacting Technical Support

At Ross Video, we take pride in the quality of our products, but if problems occur, help is as close as the nearest telephone.

Our 24-hour Hot Line service ensures you have access to technical expertise around the clock. After-sales service and technical support is provided directly by Ross Video personnel. During business hours (Eastern Time), technical support personnel are available by telephone. After hours and on weekends, a direct emergency technical support phone line is available. If the technical support person who is on call does not answer this line immediately, a voice message can be left and the call will be returned shortly. This team of highly trained staff is available to react to any problem and to do whatever is necessary to ensure customer satisfaction.

- **Technical Support:** (+1) 613-652-4886
- **After Hours Emergency:** (+1) 613-349-0006
- **E-mail:** techsupport@rossvideo.com
- **Website:** <http://www.rossvideo.com>

Before You Begin

The Tally System Console was designed to allow the user to configure basic settings of Ross Tally System devices. It helps to establish communication between the devices such as an Ultracore BCS and an TSI-4000 or a Ross Acuity production switcher.

This chapter provides an overview of the Tally System Console, and outlines how to install the Tally System Console software on your computer.

Overview

The Tally System Console is an application that is designed to work in tandem with one or more TSI systems. The application provides the user with a spreadsheet-like interface to configure their tally systems. Changes can then be made to the tally logic and uploaded to each TSI system. In addition, the Tally System Console application can be configured to limit access to certain areas of the tally configuration. This allows for minor configuration changes without the hazard of disrupting any existing tallies (e.g. source name changes).

All devices that the TSI will be communicating with will need to be configured. The Comm Port Configuration page allows for specifying the device (Production & M/C Switchers, Routers, Displays, or external GPI), how it connects (serial or Ethernet), and where it connects (COM7, IP address).




Figure 1 Example of a Workflow with the Ultracore BCS and the Tally System Console

System Requirements

Ensure the following are available before installing and using the Tally System Console:

- The Tally System Console software from the Ross Video website (the file name should be Tally System Console 3.8-Redis-on.msi.)
- A computer to install the Tally System Console with a minimum of:
 - › 1.5GB hard disc space
 - › 1GB RAM
 - › 1GHz processor
- The computer for the Tally System Console is on the same network as your Ultracore BCS and other tally system devices.

Install the Tally System Console

This section outlines how to install the Tally System Console software on your computer.

★ Consult the ***Tally System Console User Guide*** for more information on installing and configuring the Tally System Console.

To install the Tally System Console on your computer

1. Right-click the Tally System Console ***.msi install** file.
2. Click **Install**.
3. Launch the Tally System Console.
4. Click **Management > Configuration**.
5. Select the **General** tab.
6. Select the **Send configuration to TSI database** box.
7. Click **OK**.
8. Click **File > Merge Libraries**.
9. Select the file **Library10.lib**.
10. Click **OK**.

Tally System Console and Ultracore BCS

This chapter outlines how to add an Ultracore BCS to the Tally System Console.

For More Information on...

- installing and configuring the Tally System Console, refer to the *Tally System Console User Guide*.

Add the Ultracore BCS to the Tally System Console

This is required before you can configure connections between your devices and the Ultracore BCS. If you have multiple Ultracore BCS, you will need to define each one.

To add the Ultracore BCS to the Tally System Console

1. In the Tally System Console, select **Management** > **Edit TSI List**.
 2. Click **Add**.
 3. For each Ultracore BCS:
 - a. Use the **Name** field to specify a unique identifier for this Ultracore BCS in the Tally System Console.
 - b. If this is a single unit:
 - Enter the Ultracore BCS IP address in the **IP Address A** field.
 - Leave the IP Address B blank.
 - c. If the Ultracore BCS is part of a redundant system:
 - Enter the Ultracore BCS IP address of the first physical IP address in the **IP Address A** field.
 - Enter the Ultracore BCS IP address of the second physical IP address in the **IP Address B** field.
- ★ For redundant systems, do not enter the 'shared' IP address in the **IP Address** fields.
- d. Select **BCS**.
 - e. Select **Assume Online**.
 - f. Click **OK**.
 - g. Click **Done**.
4. Select **Hardware** > **Tally System Interface Units**.
5. For each Ultracore BCS:
 - a. Enter a **Name** that matches the value you entered in step 3a.
 - b. Enter an **Interface Number**.
- ★ For Ultracore BCS systems that are redundantly paired, the Interface Number value will be the same for the paired units but the IP addresses will differ. The Interface Numbers for non-paired BCS systems must differ.
- c. Enter an **IP Address** for each Ultracore BCS. Ensure the value(s) match those entered in step 3b or 3c.

Set up the Ultracore-Tally

Before proceeding, complete the following steps:

In the Tally System Console navigate to:

1. **Displays** — set up the Ultrix Multiviewer, using the Ultracore BCS IP address and Wrapped TSL 5.0 protocol. Refer to the ***Ultracore BCS User Guide*** for more details.
2. **Routers** — set up the Ultrix router using the Ultracore BCS IP address and setting the Level to 0.

In DashBoard navigate to:

1. **Ultrix > Product Info** — confirm that the Remote Controller Mode box is selected.
2. **Ultracore BCS > System > Configuration > Connections > Services** — confirm that the SW-P-08 and TSL 5.0 protocols are enabled.
3. **Ultracore BCS > System > Configuration > Connections > Protocol Services > Options** — confirm that TSL UMD v5.0 > Wrapping is set to Yes.
4. **Ultrix > Ultriscape > Layout Editor** — for each PIP:
 - a. Set **Type** to **PiP Sources**.
 - b. Select the **Tally** and **Use Tally Label** boxes.

Ross Production Switchers

This chapter summarizes the required steps for configuring the Tally System Console and Ultracore-Tally to interface with the Ross Production Switchers.

For More Information on...

- configuring your production switcher, refer to the applicable Ross user documentation.
- the Tally System Console, refer to the ***Tally System Console User Guide***.

Overview

The Ross Production Switcher communicates with the Ultracore-Tally via an ethernet connection to the Ultracore BCS. The Tally System Console also communicates with the production switcher via an ethernet connection. This requires you to:

1. Define the Ultracore BCS Settings as outlined in “**Add the Ultracore BCS to the Tally System Console**”.
2. Add the Ross Production Switcher to the Tally System Console
3. Apply the Updated Tally System Configuration
4. Specify a TCP Connection for Acuity
5. Import the Acuity Bus Maps to the Tally System Console

Add the Ross Production Switcher to the Tally System Console

This section outlines how to add the production switcher to the Tally System Console. This will enable you to define a connection between your tally system and the switcher.

To configure a tally system connection to the production switcher

1. In the Tally System Console, select **Hardware > Comm Port Setup > Production & M/C Switchers**.

The Production & M/C Switchers Device Editor opens.

2. Specify a short **Name**.

For example, *SWR* is commonly used to represent a switcher.

3. Select the **Tally Controller Unit** that will be communicating with the switcher.
4. Set the **Protocol**. Refer to **Table 1**.
5. Use the **Device Configuration > IP Addr #1** field to enter the IP address of the production switcher.

Settings for Ross Production Switchers

Table 1 summarizes the required settings for each supported Ross production switcher.

Table 1 Tally System Console — Ross Production Switcher Settings

Model	Protocol Setting	Notes
Acuity	TSL 5.0 / IP (Switcher is TCP Server)	
Carbonite Series	Switcher is TCP/IP Client	auto-detecting switcher
Carbonite Black Solo	Switcher is TCP/IP Client	

Apply the Updated Tally System Configuration

This section outlines how to apply the new connection point and save it to the tally system. This ensure that the connection settings are saved to a configuration file that is accessible to the Tally System Console.

To apply the updated tally system configuration

1. In the Tally System Console, select **File > Save as Remote Session**.
The **Save To TSI** dialog opens.
2. Select the applicable **Ultracore BCS** from the list box.
3. Edit the **Filename** as needed.
4. Perform one of the following:
 - If the currently running configuration must remain unchanged, leave the **Upload as current config and reboot** box unselected (no check-mark); or
 - Select the **Upload as current config and reboot** box if the currently running configuration must be changed to the newly uploaded configuration.
5. Click **Save to TSI**.

Specify a TCP Connection for Acuity

This section outlines how to create a TCP connection from the Acuity production switcher to the Ultracore-Tally.

To specify a TCP connection from Acuity to the Ultracore-Tally

1. On the Acuity interface, navigate to **Setup > Installation > Com Setup**.
2. Click **Type**.
3. Select **Pan NET 1**.
4. With **Type** still selected, set **Device** to **Serial Tally**.
5. Click **Select Device**.
6. Set **Device** to **TSLOUT**.
7. Click **Com Type**.
This will set the **Device** column in the port listing to **TSLOUT**.
8. With **Com Type** still selected, set **Device** to **Network TCP**.
9. Click **Com Settings**.
10. Set **Client/Server** to **Server (Many)**.
11. Navigate to the **Extra Options > Option** interface:
 - a. Set **Add Header, Value** to **No Header**.
 - b. Set **Rate, Value** to **Burst**.
 - c. Set **Output Format, Value** to **Acuity**.
12. Select **Home > Confirm**.
13. On the Acuity interface, navigate to **Setup > Installation > Com Settings**.

14. Set the following values:

- Remote IP address to 0.0.0.0
- Remote Port to 0
- Local IP address to 0.0.0.0
- Local Port to 60531

15. Select **Home** > **Confirm**.

Import the Acuity Bus Maps to the Tally System Console

The information in the Acuity Bus Maps table is important for setting the correct Tally IDs when running the Ultracore-Tally UMDs in Source mode. Refer to the **Ultracore BCS User Guide** for details on configuring this mode.

In the Tally System Console, the Tally IDs are used in:

- UMDs > Display Devices editor > Serial# / ID column, and
- Source Definitions > Switcher Inputs column.

Bus Maps Interface

To navigate to the Acuity the Bus Maps, select **Home** > **Setup** > **Bus Maps**.




Figure 2 Example of an Acuity Virtual Panel > Edit Bus Maps

On each button in the Edit Bus Maps table there is a number (Tally ID) and a name (source name). Usually the name can be correlated with router sources. For example, in **Figure 2**, Button 3 is assigned to IP-2 (002).

To add the Acuity bus maps to the Tally System Console

1. In the Tally System Console, select **Source Definitions**.
 - The table will contain at least a zero-based router input index.
 - Many of them will also contain entries in the Switcher column.
 - These entries will be the Tally ID found in the Acuity Bus Maps table.
2. In the **Source Definitions** table:

- a. Locate the row with the name found in the Acuity > Bus Maps table.
 - b. In the **Switcher Inputs** column of this row, enter the corresponding number found in Acuity > Bus Maps.
3. In the Tally System Console, select **Display Devices**.
 - a. Locate the **Tally ID** found in the Acuity > Bus Maps table.

The Tally IDs are listed in **Serial# / ID** column of the Display Devices editor.
 - b. Drag the corresponding entry from the **Source Definitions** table into the **Monitoring Styles** column of the Display Devices editor.

Ultrix Routers

This chapter summarizes the required steps for configuring the Tally System Console to interface with the Ross Ultrix routers.

For More Information on...

- configuring your Ultrix, refer to the user documentation for your router.
- the Tally System Console, refer to the ***Tally System Console User Guide***.

Overview

The Ultrix router communicates with the Ultrixcore-Tally via an ethernet connection to the Ultrixcore BCS. The Tally System Console communicates with the router via the Ultrixcore BCS. This requires you to:

1. Define the Ultrixcore BCS Settings as outlined in “**Add the Ultrixcore BCS to the Tally System Console**”.
2. Add Ultrix to the Tally System Console.

Add Ultrix to the Tally System Console

This section outlines how to add Ultrix to the list of available devices in the Tally System Console.

To add Ultrix to the Tally System Console

1. In the Tally System Console, select **Hardware > Comm Port Setup > Routers**.
The Router Device Editor opens.
2. Specify a short **Name**.
For example, RTR is commonly used to represent a router.
3. Select the **Tally Controller Unit** that will communicate with the router.
4. Set the router **Level** to **0**.
★ To specify more than one router level, separate the levels with a comma. For example, 0,1,2.
5. Select the router **Protocol** to **Ross Ultrix Router (SW-P-08 TCP/IP port)**.
6. If the router is in a single system, use the Device Configuration dialog to set the IP address of the router in the **IP Addr #1** field.
7. If the router is in redundant system, use the Device Configuration dialog to:
 - a. Set the IP address of the primary router in the **IP Addr #1** field.
 - b. Set the IP address of the secondary router in the **IP Addr #2** field.
8. Locate the **Resource Device Options** area of the Device Configuration dialog.
9. Select the **Use as configuration source** box.
10. Set the **#Inputs** field to match the number of available sources in your Ultrix router database.

Ultriscape Multiviewer

This chapter provides a general overview of the required steps for configuring the Tally System Console to interface with the Ultriscape Multiviewer feature of the Ultrix routers.

For More Information on...

- configuring your Ultriscape for the Ultrix router, refer to the ***Ultriscape User Guide***.
- the Tally System Console, refer to the ***Tally System Console User Guide***.

Overview

The Ultriscape is a feature of the Ultrix router. The Ultricore-Tally communicates with the router via the Ultricore BCS to provide access to the other devices in your tally system. This requires you to:

1. Define the Ultricore BCS Settings as outlined in “**Add the Ultricore BCS to the Tally System Console**”
2. Add an Ultriscape Multiviewer to the Tally System Console
3. Configure the PiPs in the Tally System Console
4. Assign PiPs to Destinations

Add an Ultriscape Multiviewer to the Tally System Console

This section outlines how to add an Ultriscape to the list of available devices in the Tally System Console.

To add an Ultriscape Multiviewer to the Tally System Console

1. In the Tally System Console, select **Hardware > Comm Port Setup > Displays**.
2. For each Ultriscape system:
 - a. Specify a short **Name**, such as MV1.
Depending on the location of the Ultriscape, the name can reflect the name of a control room, such as PCR1.
 - b. Select the **Tally Controller Unit** that will communicate with the Ultriscape.
 - c. Set the **Protocol** to **Multiviewer (TSL v5.0-Wrapped: MV is TCP Server)**.
 - d. Use the **Device Configuration > IP Addr #1** field to enter the IP address of the Ultriscape.

Configure the PiPs in the Tally System Console

This section outlines how to define each Ultriscape PiP in the Tally System Console.

To configure each PiP for the defined Ultriscape

1. In the Tally System Console, select **UMDs > Display Devices**.
This editor will contain a list of Ultriscape PiPs, one per line. Each PiP is associated with an Ultriscape that was defined in “**To add an Ultriscape Multiviewer to the Tally System Console**”.
2. For each PiP within Ultriscape:
 - a. Enter a **Name** for the PiP.
 - b. Select the Ultriscape with which this PiP is associated from the **Port** column menu.

- c. Enter a Tally ID into the **Serial #** column. In Ross systems this Tally ID will typically match a value in the router Destination configuration Tally ID column.
- d. Enter a value of **1** in the **Section#** column.
- e. From the **Monitoring Style** list, select **Destination**.
- f. Select a **Tally Area** (typically a Control Room) from the provided list.

The Tally Area determines which device will generate tally information for a given Ultriscape PiP.

★ An error icon displays in the Monitoring Style column of each PiP. This is a result of not yet assigning a router destination to the PiPs. This will be addressed later in the configuration workflow.

Assign PiPs to Destinations

Next you will add the Ultriscape destinations to the Tally System Console. This will allow you to assign the destinations to the PiPs in the Tally System Console.

To add the Ultriscape destinations to the Tally System Console

1. In the Tally System Console, select **UMDs > Display Devices**.
2. In the menu tree in the left part of the configuration, select **I/O and Signals > Router - Output Names**.

3. Select the **+** icon.

A list of router destinations displays.

4. Select the required Ultriscape destinations from the menu tree.
5. Drag and drop the selected destinations into the **Monitoring Style** column of the Display Devices editor.
6. At the prompt, select **Assign a single parameter to each row**.

Each PiP will now include a Monitoring Description reflecting the destination that is now assigned to each PiP.

Apply the Updated Tally System Configuration

This section outlines how to apply the new connection point and save it to the tally system. This ensure that the connection settings are saved to a configuration file that is accessible to the Tally System Console.

To apply the updated tally system configuration

1. In the Tally System Console, select **File > Save as Remote Session**.
The **Save TO TSI** dialog opens.
2. Select the applicable **Ultracore BCS** from the list box.
3. Edit the **Filename** as needed.
4. Perform one of the following:
 - If the currently running configuration must remain unchanged, leave the **Upload as current config and reboot** box unselected (no check-mark); or
 - Select the **Upload as current config and reboot** box if the currently running configuration must be changed to the newly uploaded configuration.
5. Click **Save to TSI**.

Third-Party Switchers

This chapter summarizes how to configure the Tally System Console to interface with third-party production switchers.

For More Information on...

- configuring your switcher, refer to the user documentation provided with your switcher.
- the Tally System Console, refer to the ***Tally System Console User Guide***.
- adding a Ross switcher, refer to “**Ross Production Switchers**”.

Add the Switcher to the Tally System Console

This section outlines how to add the switcher to the Tally System Console. This will enable you to define a connection between your tally system and switcher.

To configure a tally system connection to the switcher

1. In the Tally System Console, select **Hardware > Comm Port Setup > Production & M/C Switchers**.

The Production & M/C Switchers Device Editor opens.

2. Specify a short **Name**.

For example, *SWR* is commonly used to represent a switcher.

3. Select the **Tally Controller Unit** that will be communicating with the switcher.
4. Use the **Device Configuration > IP Addr #1** field to enter the IP address of the switcher.
5. Set the **Protocol**. Refer to **Table 2**.

Settings for Third-Party Switchers

Table 2 summarizes the required level and protocol for each supported third-party switcher.

Table 2 Tally System Console — Third-Party Switcher Protocols

Protocol
Sony MVS-8000X Prod. Swr.(Numeric I/O - COM port)
Sony XVS-7000 Prod. Swr.(Numeric I/O - COM port)
Sony XVS-7000 Prod. Swr.(Numeric - TSI is TCP Client)

Apply the Updated Tally System Configuration

This section outlines how to apply the new connection point and save it to the tally system. This ensures that the connection settings are saved to a configuration file that is accessible to the Tally System Console.

To apply the updated tally system configuration

1. In the Tally System Console, select **File > Save as Remote Session**.

The **Save To TSI** dialog opens.

2. Select the applicable **Ultracore BCS** from the list box.
3. Edit the **Filename** as needed.

4. Perform one of the following:
 - If the currently running configuration must remain unchanged, leave the **Upload as current config and reboot** box unselected (no check-mark); or
 - Select the **Upload as current config and reboot** box if the currently running configuration must be changed to the newly uploaded configuration.
5. Click **Save to TSI**.

Third-Party Routers

This chapter summarizes how to configure the Tally System Console to interface with third-party routers.

For More Information on...

- configuring your third-party router, refer to the user documentation provided with your router.
- the Tally System Console, refer to the ***Tally System Console User Guide***.
- adding an Ultrix router, refer to “**Ultrix Routers**”.

Add the Router to the Tally System Console

This section outlines how to add a third-party router to the list of available devices in the Tally System Console.

To add a third-party router to the Tally System Console

1. In the Tally System Console, select **Hardware > Comm Port Setup > Routers**.
The Router Device Editor opens.
2. Specify a short **Name**.
For example, RTR is commonly used to represent a router.
3. Select the **Tally Controller Unit** that will communicate with the router.
4. Set the router **Level**. Refer to **Table 3**.
- ★ To specify more than one router level, separate the levels with a comma. For example, 0,1,2.
5. Select the router **Protocol**. Refer to **Table 3**.
6. Use the **Device Configuration > IP Addr #1** field to enter the IP address of the router.

Settings for Third-Party Routers

Table 3 summarizes the required level and protocol for each supported third-party router.

Table 3 Tally System Console — Third-Party Router Settings

Protocol	Level
Evertz EQX Router (TCP/IP port)	V
Grass Valley Orbit Router (TCP/IP port)	1
Harris (LRC protocol Router TCP/IP port)	0

Apply the Updated Tally System Configuration

This section outlines how to apply the new connection point and save it to the tally system. This ensures that the connection settings are saved to a configuration file that is accessible to the Tally System Console.

To apply the updated tally system configuration

1. In the Tally System Console, select **File > Save as Remote Session**.
The **Save To TSI** dialog opens.
2. Select the applicable **Ultrixcore BCS** from the list box.

3. Edit the **Filename** as needed.
4. Perform one of the following:
 - If the currently running configuration must remain unchanged, leave the **Upload as current config and reboot** box unselected (no check-mark); or
 - Select the **Upload as current config and reboot** box if the currently running configuration must be changed to the newly uploaded configuration.
5. Click **Save to TSI**.

Third-Party Multiviewers

This chapter provides a general overview of the required steps for configuring the Tally System Console to interface with a third-party multiviewer.

For More Information on...

- configuring your multiviewer, refer to the user documentation provided with your multiviewer.
- the Tally System Console, refer to the ***Tally System Console User Guide***.

Add the Third-Party Multiviewer to the Tally System Console

This section outlines how to add a third-party multiviewer to the list of available devices in the Tally System Console.

To add a multiviewer Multiviewer to the Tally System Console

1. In the Tally System Console, select **Hardware > Comm Port Setup > Displays**.
2. For each multiviewer system:
 - a. Specify a short **Name**, such as MV1.
Depending on the location of the multiviewer, the name can reflect the name of a control room, such as PCR1.
 - b. Select the **Tally Controller Unit** that will communicate with the multiviewer.
 - c. Set the **Protocol**. Refer to **Table 4**.
 - d. Use the **Device Configuration > IP Addr #1** field to enter the IP address of the multiviewer.

Settings for Third-Party Multiviewers

Table 4 summarizes the required settings for each supported third-party multiviewer.

Table 4 Tally System Console — Third-Party Multiviewer Protocols

Protocol
Evertz VIP multi lined display (TCP/IP)
Evertz VIP display (TCP/IP)
Harris TCPIP screen (TCP/IP)
Miranda KMX screen (TCP/IP)

Configure the PiPs in the Tally System Console

This section outlines how to define each multiviewer PiP in the Tally System Console.

To configure each PiP for the defined multiviewer

1. In the Tally System Console, select **UMDs > Display Devices**.
This editor will contain a list of multiviewer PiPs, one per line. Each PiP is associated with an multiviewer that was defined in “**To add a multiviewer Multiviewer to the Tally System Console**”.
2. For each PiP within multiviewer:

- a. Enter a **Name** for the PiP.
- b. Select the multiviewer with which this PiP is associated from the **Port** column menu.
- c. Enter a Tally ID into the **Serial #** column. In Ross systems this Tally ID will typically match a value in the router Destination configuration Tally ID column.
- d. Enter a value of **1** in the **Section#** column.
- e. From the **Monitoring Style** list, select **Destination**.
- f. Select a **Tally Area** (typically a Control Room) from the provided list.
The Tally Area determines which device will generate tally information for a given multiviewer PiP.

★ An error icon displays in the Monitoring Style column of each PiP. This is a result of not yet assigning a router destination to the PiPs. This will be addressed later in the configuration workflow.

Assign PiPs to Destinations

Next you will add the multiviewer destinations to the Tally System Console. This will allow you to assign the destinations to the PiPs in the Tally System Console.

To add the multiviewer destinations to the Tally System Console

1. In the Tally System Console, select **UMDs > Display Devices**.
2. In the menu tree in the left part of the configuration, select **I/O and Signals > Router - Output Names**.
3. Select the **+** icon.
A list of router destinations displays.
4. Select the required multiviewer destinations from the menu tree.
5. Drag and drop the selected destinations into the **Monitoring Style** column of the Display Devices editor.
6. At the prompt, select **Assign a single parameter to each row**.
Each PiP will now include a Monitoring Description reflecting the destination that is now assigned to each PiP.

Apply the Updated Tally System Configuration

This section outlines how to apply the new connection point and save it to the tally system. This ensure that the connection settings are saved to a configuration file that is accessible to the Tally System Console.

To apply the updated tally system configuration

1. In the Tally System Console, select **File > Save as Remote Session**.
The **Save TO TSI** dialog opens.
2. Select the applicable **Ultracore BCS** from the list box.
3. Edit the **Filename** as needed.

4. Perform one of the following:
 - If the currently running configuration must remain unchanged, leave the **Upload as current config and reboot** box unselected (no check-mark); or
 - Select the **Upload as current config and reboot** box if the currently running configuration must be changed to the newly uploaded configuration.
5. Click **Save to TSI**.

