360 Systems DigiCart II Audio Recorder

Requirements

- Audio Server Interface Software Option
- Serial Interface Cables

Port Connections

	Switcher		Audio Server
Communications	REMOTE Port (female)	⇨	Serial Port 2[a]

a. The DigiCart II cannot be connected to the switcher via a Serial Port Expander, such as the BSS4.

Pinouts

Switcher	Audio Server
2 (Rx-)	5 (Tx-)
3 (Tx+)	8 (Rx+)
7 (Rx+)	4 (Tx+)
8 (Tx-)	9 (Rx-)

Switcher Setup

1. Press **HOME** ⇨ **Setup** ⇨ **Installation** ⇨ **Com Setup** ⇨ **Type**.

   - Use the **Com Port** knob to select the **REMOTE X** port that you connected the DigiCart II to.
   - Use the **Device** knob to select **Audio Server**.

2. Press **Select Device**.

   - Use the **Device** knob to select **DigiCart**.

3. Press **Com Type**.

   - Use the **Type** knob to select **RS-422**.

4. Press **Com Settings**.

   - Use the **Baud** knob to select **38400**.
   - Use the **Parity** knob to select **EVEN**.

5. Press **Extra Options**.

Extra Options	Value
Bus Address	2 (default)

6. Press **HOME** ⇨ **Confirm**.

Device Setup

To control the DigiCart II from the switcher, the DigiCart II must be enabled for remote control operations. Refer to the 360 Systems DigiCart II Audio Recorder documentation for more information.

Compatibility

Audio Server	Version
360 Systems DigiCart II Audio Recorder	--
Switchers	
Synergy 1 SD	16.0 or higher
Synergy Series SD	18.0 or higher
Synergy MD/X	8.2 or higher
Vision MD/X	8.2 or higher
Vision QMD/X	8.2 or higher
Vision MultiPanel Support	--
Automation	
OverDrive	7.0 or higher
Port Expanders	
BSS4	✘
Comtrol DeviceMaster	✘