


Basic Cabling

⚠ CAUTION: Before you set up and operate this product, refer to the Important Safety and Regulatory Notices document included in the shipping box.

Need Help?

Technical Support:
 1-844-652-0645 (North America)
 +800 3540 3545 (International)
 Email: techsupport@rossvideo.com



When contacting technical support: please provide the information listed on the following label, which is located on the bottom-right of the chassis on the com port bracket.

XXX-HW-CORE-V3
 Rev. #
 #####

- 1** Use the supplied Rack Mount Kit to mount the system in a 19" EIA equipment rack.
For information on installing the chassis in a rack, see the provided document "Installing the Chassis in a Rack".
- 2** Plug the supplied Keyboard into one of the **USB** ports.
- 3** Plug the supplied Mouse into one of the **USB** ports.
- 4** Connect a Monitor (customer supplied) to any of the three mini-display ports using the mini-display port to display port adapter.
KVM extenders (customer supplied) are required when the system monitor, keyboard, and mouse are located remotely from the rack room.
- 5** Plug an Ethernet cable from your Local Area Network into either the **1G (a)** or **10G (b) Ethernet** port.
The system can be connected to the Internet or restricted production network. The network connection is also used to distribute assets and for the RossTalk/Smart GPI feature.
- 6** Connect power cords from the AC ports on the system to the mains power.
The system power supplies are auto-sensing and can use either 110 VAC or 220 VAC.