



The User buttons along the top of the crosspoint row can be assigned to a number of different functions from the Personality menu. The assignments shown here are default values that allow you to easily access different switcher functions. The button caps to be replaced are shown in red and the replacement button cap is included in this kit.

Additional inserts can be found in the Documentation kit for your TouchDrive control panel. If an insert for the function you want to assign to a User button is not in the kit, you can download a template from the Ross website to print your own inserts.

User Buttons - 25/15 Buttons



Printable Inserts

If you do not have the replacement button caps than came with your TD panel, you can create replacement inserts for your existing buttons.

Print this page out on a clear lexan and cut out the inserts shown below. Ensure that you print the page at **Actual Size** to ensure the inserts are the proper size.

