

## XPression™ GO! AJA® Io®XT Driver Installation

★ This document explains how to install the AJA IoXT driver for XPression GO! systems running XPression version 6.2 or lower and XPression version 6.5 with the AJA Legacy driver.

### Prerequisites

XPression GO! has been qualified to work with AJA Driver version 10.3.5.25. Driver versions 10.4 and higher are not supported.

★ Prior to beginning installation, uninstall all previous versions of the AJA IoXT driver from the Windows® **Control Panel**.

★ Install the AJA IoXT driver prior to adding the **AJA Video (legacy)** framebuffer into XPression.


### Installation

To install the AJA IoXT driver:

1. Connect the AJA IoXT to the laptop with a Thunderbolt™ cable.
2. Turn on the AJA IoXT.
3. Turn on the laptop.
4. Insert the supplied driver disk into the laptop.
5. Run the **KonaDrivers-10.3.5.25.msi** driver package.


To verify the driver has been installed:

1. In the Windows **Control Panel**, click **Hardware and Sound**.




The **Hardware and Sound** screen opens.

## 2. Click **Device Manager**.



The **Device Manager** window opens.

## 3. Verify that **AJA IOXT SDI I/O** appears under **Sound, video and game controllers**.



## 4. Double-click **Sound, video and game controllers**.

The **AJA IOXT SDI I/O Properties** window opens.

## 5. Verify that **Driver Version** is 10.3.5.25.

