



1

Turn OFF frame power.



2


Remove the screws securing the rear plate to the fan assembly and remove the plate.



3


Unplug the fan cable for the fan you are replacing.

You may have to cut the cable ties to remove the fan.



4


Remove the screws securing the fan to the fan assembly and remove the fan.



5

Install the new fan using the screws you removed.


Make sure not to pinch the fan cable behind the fan when installing it.



6

Re-connect the fan cable and turn the frame power ON.

Ensure that the new fan is working properly before replacing the rear plate.



7

Install the rear plate using the screws you removed.

