


1

Remove Frame Door.



2


Turn OFF frame power.



3


Unplug the fan cable for the fan you are replacing.

You may have to cut the cable ties to remove the fan.



4


Remove the screws securing the fan to the frame and remove the fan and the front bezel.



5

Install the new fan and front bezel using the screws you removed.

Make sure not to pinch the fan cable behind the fan when installing it.



6

Re-connect the fan cable and turn the frame power ON.

Ensure that the new fan is working properly before replacing the frame door.

