Yamaha 02R96

Yamaha 02R96

Requirements

- Large Audio Mixer Interface Software Option
- SMC Serial to MIDI Converter
- MIDI Interface Cables (x2)
- Serial Interface Cables (DB9 to DB9)

Port Connections

	Switcher		SMC
Serial Connection	REMOTE Port (female)	⇒	SERIAL Port (female)
	SMC		Audio Mixer
	SIVIC		Audio Mixei
MIDI Connection	MIDI Out	⇒	MIDI In

Cable Connectors




Figure 1 DB9 to DB9 Cable

Pinouts

Switcher	SMC
2 (Rx-)	2 (Tx-)
3 (Tx+)	3 (Rx+)
7 (Rx+)	7 (Tx+)
8 (Tx-)	8 (Rx-)

Switcher Setup

To Set Up Communications

- Press HOME ⇒ Setup ⇒ Installation ⇒ Com Setup ⇒ Type.
 - Use the Com Port knob to select the Remote X port that you connected the 02R96 to.
 - Use the **Device** knob to select **Audio Mixer**.

- 2. Press Select Device.
 - Use the **Device** knob to select **Ya 02R96**.
- 3. Press Com Type.
 - Use the Type knob to select RS-422.
- 4. Press Com Settings.
 - Use the Baud knob to select 38400.
 - Use the **Parity** knob to select **NONE**.
- 5. Press Extra Options.

Extra Options	Value
Converter	SMC
Mixers (ganged together)	1 (default)
Version (of 02R96)	1 (default)
Post-fade delay	5 (default)

6. Press **HOME** ⇒ **Confirm**.

To Assign Audio Channels to BNCs

- 1. Press HOME ⇒ Setup ⇒ Installation ⇒ BNC ⇒ Audio.
- 2. Use the **BNC** knob to select the Input BNC that you want to assign an audio channel to.
- **3.** Use the **Audio 1** knob to select an audio channel, or group, that you want to assign to the selected Input BNC.
- **4.** Use the **Audio 2** knob to select another audio channel, or group, that you want to assign to the selected Input BNC.
- 5. Press HOME ⇒ Confirm.

Refer to your switcher manual for information on creating audio groups, or setting default audio levels.

Device Setup

- Press the SETUP function button in the Display Access Group to display the SETUP Menu.
- Press the MIDI/HOST tab to display the MIDI/HOST SETUP Menu.
 - Tx PORT Use the Parameter Dial to set this to **MIDI**.
 - Rx PORT Use the Parameter Dial to set this to MIDI.
- Press the MIDI function button in the Display Access Group to display the MIDI Menu.
- **4.** Press the **SETUP** tab to display the **MIDI SETUP Menu**.
- **5.** Use the **Cursor** buttons to navigate to the following (you will have to press **ENTER** after each selection):



- Tx CH Use the Parameter Dial to set this to 1.
- Rx CH Use the Parameter Dial to set this to 1.

Note: If you are ganging multiple audio mixers, you must set the second Audio Mixer to **Tx CH 2** and **Rx CH 2**.

• Set the remaining parameters as indicated:

Setting	Tx	Rx	OMNI	ЕСНО
Program Change	ON	ON	OFF	OFF
Control Change	OFF	OFF	OFF	
Param Change	ON	ON		OFF
Bulk		OFF		
Other Commands				OFF

• Fader Resolution - Use the Parameter Dial to set this to LOW.

Compatibility

Audio Mixer	Version	
Yamaha 02R96		
Switchers		
Synergy 1 SD		
Synergy Series SD		
Synergy MD/X		
Vision MD/X		
Vision QMD/X	15.0a	
Vision MultiPanel Support		
Automation		
OverDrive	12.0	
Port Expanders		
BSS4	✓	
Comtrol DeviceMaster	✓	

