

360 Systems DigiCart/E Audio Recorder

Requirements

- Audio Server Interface Software Option
- Serial Interface Cables (pins 6 and 4 must be tied together)

Port Connections

	Switcher		Audio Server
Communications	REMOTE Port (female)	⇒	AUX Serial Port ^a

- The DigiCart/E cannot be connected to the switcher via a Serial Port Expander, such as the BSS4.

Pinouts

Switcher	DigiCart/E
2 (Rx-)	8 (Tx-)
3 (Tx+)	7 (Rx+)
7 (Rx+)	3 (Tx+)
8 (Tx-)	2 (Rx-)

Switcher Setup

- Press **HOME** ⇒ **Setup** ⇒ **Installation** ⇒ **Com Setup** ⇒ **Type**.
 - Use the **Com Port** knob to select the **REMOTE X** port that you connected the DigiCart/E to.
 - Use the **Device** knob to select **Audio Server**.
- Press **Select Device**.
 - Use the **Device** knob to select **DigiCart**.
- Press **Com Type**.
 - Use the **Type** knob to select **RS-422**.
- Press **Com Settings**.
 - Use the **Baud** knob to select **38400**.
 - Use the **Parity** knob to select **EVEN**.
- Press **Extra Options**.

Extra Options	Value
Bus Address	2 (default)

- Press **HOME** ⇒ **Confirm**.

Device Setup

- On the **SETUP MENU**, select **SET AUX PROTOCOL**.
- Select **E-BUS** to set the Aux Bus Protocol.
- Press **ENTER**.

Important: During operation from the switcher, the DigiCart/E must be enabled for remote control. The **REMOTE CONTROL ADDRESS** must be set to 02.

Compatibility

Audio Server	Version
360 Systems DigiCart/E Audio Recorder	--
Switchers	
Synergy 1 SD	16.0 or higher
Synergy Series SD	18.0 or higher
Synergy MD/X	8.2 or higher
Vision MD/X	8.2 or higher
Vision QMD/X	8.2 or higher
Vision MultiPanel Support	--
Automation	
OverDrive	7.0 or higher
Port Expanders	
BSS4	✘
Control DeviceMaster	✘



