

## Sony MiniDisc MDS-E12 MD Player

### Requirements

- Audio Server Interface Software Option
- Serial Interface Cables (pins 4 and 6, and pins 7 and 8 are tied together on the Sony MiniDisc)

### Port Connections

	Switcher		Audio Server
Communications	REMOTE Port (female)	⇒	RS232C Port

### Pinouts

Switcher	Sony MiniDisc
2 (Tx)	2 (Rx)
3 (Rx)	3 (Tx)
5 Ground	5 Ground

### Switcher Setup

#### To Set Up Communications

1. Press **HOME** ⇒ **Setup** ⇒ **Installation** ⇒ **Com Setup** ⇒ **Type**.
  - Use the **Com Port** knob to select the **REMOTE X** port that you connected the Sony MiniDisc to.
  - Use the **Device** knob to select **Audio Server**.
2. Press **Select Device**.
  - Use the **Device** knob to select **MiniDisc**.
3. Press **Com Type**.
  - Use the **Type** knob to select **RS-232 (RS-232 NULL on the Synergy 1)**.
4. Press **Com Settings**.
  - Use the **Baud** knob to select **9600**.
  - Use the **Parity** knob to select **NONE**.
5. Press **HOME** ⇒ **Confirm**.

### Device Setup

Ensure the port on the Sony MiniDisc that is connected to the switcher is configured for RS-232.

### Compatibility

Audio Server	Version
Sony MiniDisc MDS-E12	--
Switchers	
Synergy 1 SD	--
Synergy Series SD	--
Synergy MD/X	--
Vision MD/X	--
Vision QMD/X	17.0
Vision MultiPanel Support	--
Automation	
OverDrive	12.0
Port Expanders	
BSS4	✓
Control DeviceMaster	✓





Video Production Technology