

Rack Mounting

1 Rack Mount

Unpack and mount your Ultracool in a 19" wide EIA equipment rack.

Note: If Ultracool will be used with an Ultrix router, ensure to install the Ultracool directly above the router.

Network Cabling

2 LAN or Network Connection

Plug an Ethernet cable from your network into the **ENET** port. This is the network connection for Ultracool.

Note: Ultracool must be connected to the same network as the other devices in your routing system.

Power Cabling

3

3a Connect the supplied power supply DC cable into the **PWR1** socket.


3b If available, connect the redundant power supply DC cable into the **PWR2** socket.

CAUTION: Connect the DC Power of the power supply to the PSU port(s) on the Ultracool chassis before connecting the power supply to the power source.

Note: The Ultracool powers on automatically when a power supply is plugged in.

Maximum Power Consumption	
Power	60W max. 50W (all fans operation at 100% RPM)
Current	2.5A
Voltage	15VDC

For the latest power numbers for your configuration, refer to the Ross Configuration Tool on our website.



Setting the IP Address

- 4**
- 4a** Launch DashBoard on your PC desktop.
 - 4b** Select **File > Show Walkabout**.
 - 4c** Click **Refresh**.
 - 4d** Locate the Ultracool in **Walkabout**.
 - 4e** Use the **Address** field to specify the IP address. The default is 192.168.20.125.
 - 4f** Click **Reboot**.
 - 4g** Refer to the *Ultracool User Guide* for additional steps.

Ultrix Communications

- 5**
- 5a** Launch DashBoard on your PC desktop.
 - 5b** Double-click the Ultracool sub-node.
 - 5c** Select the **Setup** tab.
 - 5d** Set the **Fan Speed** to **Auto**.
 - 5e** Set the **Device Control** to **Manual IP**.
 - 5f** Use the **Ultrix IP Address** to specify the address of the Ultrix router that will control the Ultracool.
 - 5g** Press **Enter**.
 - 5h** Click **Apply** to establish connection.

? Have a question? Call our free, 24-hour technical support hotline to speak with a live product specialist located right here in our facility.
Tel: (+1) 613 • 652 • 4886
Email: techsupport@rossvideo.com