

CAUTION: There is a foam insert inside the OGX-FR chassis (between the frame door and card slots). This foam insert **MUST** be removed before powering the unit on. Failure to remove the foam insert will damage your system.

1.0 Installing in a Rack Frame



Important: Maintain the following minimum dimensions within the equipment rack:

- Minimum 2" (5.08cm) clearance both right and left sides of the chassis with unrestricted vertical airflow.
- Minimum 5" (12.7cm) clearance at the chassis rear with unrestricted vertical airflow.

Note: If you do not have the optional FSB-OGX Rear Support Brackets Kit for your OGX-FR, perform only step 2.

Tip: Ensure that your openGear cards, rear modules, and power supplies are fully seated inside the OGX-FR chassis.



