

## LAMA Mix

Caprica can support up to 240 audio mixer faders. Source mapping is not available for audio mixers.

### Requirements

- Large Audio Mixer Interface Software Option
- Ethernet Cable

### Port Connections

Communications		
Audio Mixer Ethernet	>	Local Area Network Ethernet

### Remote Device Port Configuration Settings

Use the following procedure to configure a remote device for your LAMA Mix audio mixer on the Caprica Server:

1. Use the current version of **DashBoard** software to connect to your **Caprica Server**.
2. In the **DashBoard Tree View**, double-click the **Port Configuration** node of your Caprica Server.
3. In the **Port Configuration Summary** table, double-click a **REMOTE#** port in the **Port** column.
4. In the **Configure REMOTE#** panel, click **Audio Mixer**.
5. Click **RAP**.
6. Click **Network Settings**.
7. Use the following settings to configure the **Network Settings** for your LAMA Mix audio mixer:
  - **Ethernet Role** — Client
  - **Remote IP Address** — IP address of the LAMA Mix audio mixer
  - **Remote Port** — Port number that your LAMA Mix audio mixer uses to communicate with other devices (default: 9999). This port number must match the port number set in the **Engine Preferences** dialog box on the LAMA Mix audio mixer,
  - **Local IP Address** — 0.0.0.0
  - **Local Port** — 0
  - **Protocol** — TCP
8. Click **Apply Changes** to save the network settings.

### Device Settings

Use the following procedure to configure the device settings for your LAMA Mix audio mixer on the Caprica Server:

1. Click **Device Settings**.
2. Click the **TargetMachine** setting button and then select **Generic** from the **Select TargetMachine** list.
3. Click the **Ctrl Master** setting button and then select the Master fader to control through OverDrive from the **Select Ctrl Master** list. The available options are: **M1**, **M2**, **S1**, or **S2**
4. In the **Multiplier** box, enter or select a value from **1** to **10** to set the amount to multiply sound output.
5. For the **Fader Range** setting, click the range type for the audio mixer faders. The available options are as follows:
  - **Linear**
  - **PseudoLog**
6. For the **AutoUnmute** setting, click one of the following buttons to control automatic unmute:
  - **Yes** — automatically unmute audio faders when the audio level is changed.
  - **No** — leave audio faders muted when the audio level is changed.
7. Click **Apply Changes** to save the device settings.
8. Click **Done** to close the Configure REMOTE# panel.

### For More Information on...

- configuring remote devices for OverDrive systems that contain a Caprica Server, refer to the *Caprica User Guide*.

### Audio Configuration

Use the following procedure to configure your LAMA Mix audio mixer master/pgm out channel:

1. At the bottom of the **Device View**, click **Audio Configuration**.
2. In the **Audio Configuration** client, click the **Channel Names** tab.
3. In the **Channel** column of the **Audio Channels** table, double-click the **LAMA Mix audio mixer master/pgm out** channel.
4. For the **Include Channel** setting, click **No** to exclude the channel from OverDrive.
5. Click **Apply Changes**.

## Compatibility

Automation	Version
OverDrive	23.3 or higher
Caprica Server	23.3 or higher

## Contacting Technical Support

Technical Support is staffed by a team of experienced specialists ready to assist you with any question or technical issue.

Ross Video has technical support specialists strategically located around the globe to ensure a prompt response to technical inquiries. Our primary technical support center is located in Ottawa, Ontario, Canada. In addition, we have offices in The United Kingdom (London), Australia (Sydney), and Singapore with satellite locations in New York City, The Netherlands, and China. As we expand our presence globally, we are constantly evaluating other key locations to have a local technical support specialist in order to better service our customers.

### North America

Our North America center located in Ottawa, Ontario, Canada and is open Monday to Friday 8:30 a.m. to 6:00 p.m. EST, with 24/7/365 on-call service after hours.

Our telephone number is: +1-613-686-1557

Toll free within North America: +1 833-859-0499

### EMEA

Our EMEA center is open Monday to Friday 8:30 a.m. to 5:00 p.m. GMT. After hours support is provided by our North America location.

Our telephone number is: +44 (0)1189502446

International toll free: +800 3540 3545

If the local support specialist is not available, your call will be transferred automatically to our North America center.

### Australia

Our Sydney, Australia office is located in Alexandria, NSW.

Our local support telephone number is: 1300 007 677

If the local support specialist is not available, your call will be transferred automatically to our North America center.

### Online

E-mail: [techsupport@rossvideo.com](mailto:techsupport@rossvideo.com)

Website: open a support request using the link <https://support.rossvideo.com/> to open a support request.

### Copyright

© 2014 - 2025 Ross Video Limited. Ross®, MLE®, OverDrive®, GlobalView®, RundownControl™, DirectControl™, DirectAudio™, DirectAUXaudio™, DirectCamera™, DirectServer™, QuickTurn™, RapidRestore™, SideShot™, SideSlide™, SideStick™, OverDrive Gateway™, LiveLink™, and any related marks are trademarks or registered trademarks of Ross Video Limited. All other trademarks are the property of their respective companies. PATENTS ISSUED and PENDING. All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, mechanical, photocopying, recording or otherwise, without the prior written permission of Ross Video. While every precaution has been taken in the preparation of this document, Ross Video assumes no responsibility for errors or omissions. Neither is any liability assumed for damages resulting from the use of the information contained herein.