


## Ross Video Graphite CPC Switcher

### Cable Connections

In an OverDrive system, a Graphite switcher connects to the OverDrive Server through a Caprica Server.



### Switcher Device Port Configuration Settings

Use the following procedure to configure a switcher device for your Graphite switcher on the Caprica Server:

1. Use the current version of **DashBoard** software to connect to your **Caprica Server**.
2. In the **DashBoard Tree View**, double-click the **Port Configuration** node of your Caprica Server.
3. In the **Port Configuration Summary** table, double-click **SWITCHER1** in the **Port** column.
4. In the **Configure SWITCHER1** panel, click **Switcher**.
5. Click **Graphite**.
6. Click **Network Settings**.
7. Use the following settings to configure the **Network Settings** for your switcher device:
  - **Ethernet Role** — Client
  - **Remote IP Address** — IP address of your Graphite frame
  - **Remote Port** — 5253
  - **Local IP Address** — 0.0.0.0
  - **Local Port** — 0
  - **Protocol** — TCP
8. Click **Device Settings**.
9. Use the **MemRecallDelay** box to enter or select the number of fields to wait for memory recalls to complete.
10. Use the **CutTimeout** box to enter or select the number of fields to wait for Cut transitions to complete.
11. Use the **AutoTransDelay** box to enter or select the number of fields to wait for AutoTrans transitions to complete.
12. Click **PP Mapto** to select the ME on your Carbonite Ultra switcher to map to the Program bus in Caprica.
13. Click **ME1 Mapto** to select the ME on your Carbonite Ultra switcher to map to ME1 in Caprica.
14. Click **ME2 Mapto** to select the ME on your Carbonite Ultra switcher to map to ME2 in Caprica.
15. Click **ME3 Mapto** to select the ME on your Carbonite Ultra switcher to map to ME3 in Caprica.
16. Click **ME4 Mapto** to select the ME on your Carbonite Ultra switcher to map to ME4 in Caprica.
17. Click **ME5 Mapto** to select the ME on your Carbonite Ultra switcher to map to ME5 in Caprica.
18. Click **ME6 Mapto** to select the ME on your Carbonite Ultra switcher to map to ME6 in Caprica.
19. Use the **MemRecallMode** buttons to set memory recall method to use. The available settings are as follows:
  - **UseSwMode** — use the memory recall mode set on the switcher to execute memory recalls.
  - **Program** — use the Program memory recall mode to execute memory recalls.
20. Use the **Use Accel** buttons to control the use of an experimental feature to improve communication performance between your Carbonite Ultra switcher and Caprica Server. The available settings are as follows:
  - **Yes** — use this experiment feature.
  - **No** — do not use this experiment feature.
21. Use the **Monitor XPN** buttons to set the connection between the Graphite CPC switcher and XPression for live production. The available settings are as follows:
  - **Yes** — treat the Graphite CPC switcher as not connected to XPression, just like the Caprica Server not being able to connect to the Graphite CPC switcher. Most users should select this setting.
  - **No** — let the Caprica Server try control the Graphite CPC switcher, even if it is not connected to XPression.
22. Use the **Number of Inputs** box to enter or select the number of inputs on your Graphite CPC frame.
23. Click **Apply Changes** to save the switcher settings.
24. Click **Done** to close the Configure SWITCHER1 panel.

## For More Information on...

- configuring a Graphite Switcher for OverDrive, refer to the *Caprica User Guide*.

## Compatibility

Switcher	Version
Ross Video Graphite	1.X

Automation	Version
OverDrive	18.3
Caprica Server	5.3c

## Limitations

The following limitations apply to an OverDrive system configured with a Graphite switcher connected to the OverDrive system through a Caprica Server:

- The Fade To Black transition in Overdrive does not function. You can use the RossTalk FTB command or a GPI to make a Graphite switcher fade to and from black.
- You can not fully control your production system through the Graphite panel or DashBoard UI.
- When MediaWipe transitions are pre-loaded into channels 1 and or 2 before the switcher connects to the Caprica Server, launching a MediaWipe will fail. To work around this limitation, run your MediaWipe custom controls in Caprica as part of your pre-show preparation.

## Contacting Technical Support

Technical Support is staffed by a team of experienced specialists ready to assist you with any question or technical issue.

Ross Video has technical support specialists strategically located around the globe to ensure a prompt response to technical inquiries. Our primary technical support center is located in Ottawa, Ontario, Canada. In addition, we have offices in The United Kingdom (London), Australia (Sydney), and Singapore with satellite locations in New York City, The Netherlands, and China. As we expand our presence globally, we are constantly evaluating other key locations to have a local technical support specialist in order to better service our customers.

## North America

Our North America center located in Ottawa, Ontario, Canada and is open Monday to Friday 8:30 a.m. to 6:00 p.m. EST, with 24/7/365 on-call service after hours.

Our telephone number is: +1-613-686-1557

Toll free within North America: +1 833-859-0499

## EMEA

Our EMEA center is open Monday to Friday 8:30 a.m. to 5:00 p.m. GMT. After hours support is provided by our North America location.

Our telephone number is: +44 (0)1189502446

International toll free: +800 3540 3545

If the local support specialist is not available, your call will be transferred automatically to our North America center.

## Australia

Our Sydney, Australia office is located in Alexandria, NSW.

Our local support telephone number is: 1300 007 677

If the local support specialist is not available, your call will be transferred automatically to our North America center.

## Online

E-mail: [techsupport@rossvideo.com](mailto:techsupport@rossvideo.com)

Website: open a support request using the link <https://support.rossvideo.com/> to open a support request.

## Copyright

© 2014 - 2024 Ross Video Limited. Ross®, MLE®, OverDrive®, GlobalView®, RundownControl™, DirectControl™, DirectAudio™, DirectAUXaudio™, DirectCamera™, DirectServer™, QuickTurn™, RapidRestore™, SideShot™, SideSlide™, SideStick™, OverDrive Gateway™, LiveLink™, and any related marks are trademarks or registered trademarks of Ross Video Limited. All other trademarks are the property of their respective companies. PATENTS ISSUED and PENDING. All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, mechanical, photocopying, recording or otherwise, without the prior written permission of Ross Video. While every precaution has been taken in the preparation of this document, Ross Video assumes no responsibility for errors or omissions. Neither is any liability assumed for damages resulting from the use of the information contained herein.