

Lawo UHD

You must configure the Lawo UHD audio mixer first before configuring a Caprica device for it. The Lawo UHD audio mixer must be configured in following order:

1. Inputs
2. VCA Groups
3. Surrounds

The Caprica device that you configure for your Lawo UHD audio mixer must match the input configuration of the audio mixer.

Caprica can support up to 240 audio mixer faders. Source mapping is not available for audio mixers.

Requirements

- Large Audio Mixer Interface Software Option
- Ethernet Cable

Port Connections

Communications		
Audio Mixer Ethernet	>	Local Area Network Ethernet

Remote Device Port Configuration Settings

Use the following procedure to configure a remote device for your Lawo UHD audio mixer on the Caprica Server:

1. Use the current version of **DashBoard** software to connect to your **Caprica Server**.
2. In the **DashBoard Tree View**, double-click the **Port Configuration** node of your Caprica Server.
3. In the **Port Configuration Summary** table, double-click a **REMOTE#** port in the **Port** column.
4. In the **Configure REMOTE#** panel, click **Audio Mixer**.
5. Click **LawoUHD**.
6. Click **Network Settings**.
7. Use the following settings to configure the **Network Settings** for your Lawo UHD audio mixer:
 - **Ethernet Role** — Client
 - **Remote IP Address** — IP address of the Lawo UHD audio mixer
 - **Remote Port** — 9000
 - **Local IP Address** — 0.0.0.0
 - **Local Port** — 0
 - **Protocol** — TCP

8. Click **Apply Changes** to save the network settings.

Device Settings

A Lawo UHD audio mixer Caprica device can use a maximum of 240 inputs, including the set number of Inputs, VCA Groups, and Surrounds. The following example uses 16 inputs:

- **Inputs** — 10
- **VCA Groups** — 3
- **Surrounds** — 3

Using the example configuration, the Caprica Audio Control client would display faders 1 to 10 as the Inputs, the next 3 faders as VCA Groups, and the next 3 faders as Surrounds. Even though each Surround controls numerous faders on the Lawo UHD audio mixer, the Caprica Audio Control client only displays a single fader for each Surround.

Use the following procedure to configure the device settings for your Lawo UHD audio mixer on the Caprica Server:

1. Click **Device Settings**.
2. Click **Ctrl Master** to select the master channel to control.
3. In the **No. Of Inputs** box, enter or select the number of inputs used on the Lawo UHD audio mixer and make available in Caprica.
4. In the **No. Of VCAs** box, enter or select the number of VCA groups used on Lawo UHD mixer and make available in Caprica.
5. In the **No. Of Surrounds** box, enter or select the number of Surrounds used on the Lawo UHD audio mixer and make available in Caprica.
6. Click **Apply Changes** to save the device settings.
7. Click **Done** to close the Configure REMOTE# panel.

For More Information on...

- configuring remote devices for OverDrive systems that contain a Caprica Server, refer to the *Caprica User Guide*.

Device Setup

- You must assign faders to the Lawo UHD audio mixer channels that you want to control through Caprica.

Compatibility

Automation	
OverDrive	21.3 or higher
Caprica Server	8.3 or higher

Contacting Technical Support

Technical Support is staffed by a team of experienced specialists ready to assist you with any question or technical issue.

Ross Video has technical support specialists strategically located around the globe to ensure a prompt response to technical inquiries. Our primary technical support center is located in Ottawa, Ontario, Canada. In addition, we have offices in The United Kingdom (London), Australia (Sydney), and Singapore with satellite locations in New York City, The Netherlands, and China. As we expand our presence globally, we are constantly evaluating other key locations to have a local technical support specialist in order to better service our customers.

North America

Our North America center located in Ottawa, Ontario, Canada and is open Monday to Friday 8:30 a.m. to 6:00 p.m. EST, with 24/7/365 on-call service after hours.

Our telephone number is: +1-613-686-1557

Toll free within North America: +1 833-859-0499

EMEA

Our EMEA center is open Monday to Friday 8:30 a.m. to 5:00 p.m. GMT. After hours support is provided by our North America location.

Our telephone number is: +44 (0)1189502446

International toll free: +800 3540 3545

If the local support specialist is not available, your call will be transferred automatically to our North America center.

Australia

Our Sydney, Australia office is located in Alexandria, NSW.

Our local support telephone number is: 1300 007 677

If the local support specialist is not available, your call will be transferred automatically to our North America center.

Online

E-mail: techsupport@rossvideo.com

Website: open a support request using the link <https://support.rossvideo.com/> to open a support request.

Copyright

© 2014 - 2024 Ross Video Limited. Ross®, MLE®, OverDrive®, GlobalView®, RundownControl™, DirectControl™, DirectAudio™, DirectAUXaudio™, DirectCamera™, DirectServer™, QuickTurn™, RapidRestore™, SideShot™, SideSlide™, SideStick™, OverDrive Gateway™, LiveLink™, and any related marks are trademarks or registered trademarks of Ross Video Limited. All other trademarks are the property of their respective companies. PATENTS ISSUED and PENDING. All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, mechanical, photocopying, recording or otherwise, without the prior written permission of Ross Video. While every precaution has been taken in the preparation of this document, Ross Video assumes no responsibility for errors or omissions. Neither is any liability assumed for damages resulting from the use of the information contained herein.