

Merging Technologies Ovation Media Server

Requirements

- Large Audio Mixer Interface Software Option
- Ethernet Cable

Switcher Setup

To Set Up Communications

1. Press **HOME** ⇒ **Setup** ⇒ **Installation** ⇒ **Com Setup** ⇒ **Type**.
 - Use the **Com Port** knob to select the **REMOTE X** port that you want to assign the Ovation to.
 - Use the **Device** knob to select **Audio Mixer**.
2. Press **Select Device**.
 - Use the **Device** knob to select **RAP**.
3. Press **Com Type**.
 - Use the **Type** knob to select **Network TCP**.
4. Press **Com Setting**.
5. Use the **Client/Server** knob to select **Server**.
 - In the **Local IP Address** field, enter **0.0.0.0**.
 - Leave the **Local IP Port** field as is.
6. Press **Extra Options**.

Extra Options	Value
OD Master	M1 (default)
TargetMachine	Generic

7. Press **HOME** ⇒ **Confirm**.

To Assign Audio Channels to BNCs

1. Press **HOME** ⇒ **Setup** ⇒ **Installation** ⇒ **BNC** ⇒ **Audio**.
2. Use the **BNC** knob to select the Input BNC that you want to assign an audio channel to.
3. Use the **Audio 1** knob to select an audio channel, or group, that you want to assign to the selected Input BNC.
4. Use the **Audio 2** knob to select another audio channel, or group, that you want to assign to the selected Input BNC.
5. Press **HOME** ⇒ **Confirm**.

Refer to your switcher manual for information on creating audio groups, or setting default audio levels.

Device Setup

The Merging Ovation must have the OASIS security USB key installed.

1. Click **Settings** > **All Settings** > **Mixer Remote Control**.
2. Click **Enable**.
3. On the protocol list, click **RAP**.
4. Enter the IP address and port on the switcher you are connecting to.
5. Click **OK**.

Compatibility

Audio Mixer	Version
Merging Ovation	3.2.3
Switchers	
Synergy 1 SD	--
Synergy Series SD	--
Synergy MD/X	--
Vision MD/X	--
Vision QMD/X	15.0a
Vision MultiPanel Support	--
Automation	
OverDrive	12.0
Port Expanders	
BSS4	✘
Control DeviceMaster	✘





Video Production Technology